



20M EH Antenna - 1 1/2" PVC

20 Meters

Phasing Coil 2 turns

Tuning Coil * 15 turns

All coils use # 14 enamel wire

Spacing

Phasing Coil is at least 1/2" above top of bottom cylinder.

Tuning Coil is 2" below bottom cylinder.

Cylinder spacing is 1 cylinder diameter (1.9").

Web Site - <http://WWW.WB5CXC.COM>